



# M Fire Alarm Control Panel Quick Reference Sheet

14820 East Sprague Ave, Spokane, WA 99214-0129 Phone (509) 926-6277 Fax (509) 924-4980 www.monaco.com

## Overview

This Quick Reference Sheet summarizes some of the programming and operational information covered in detail in the M-series Fire Alarm Control Panel (FACP) IOM manuals. Refer to the M-series FACP IOM manuals for detailed instructions.

Place this Quick Reference Sheet in the M-series FACP enclosure; it fits behind the battery. Do not remove it! The information on this sheet needs to be available as a reference:

Main Menu
1 CONFIGURATION MENU
2 LIST ALARMS
3 LIST TROUBLES
4 POWER SUPPLY METERS
5 WALKTEST
6 TRANSMITTER ENABLE
7 TRANSMITTER DISABLE
8 CHANGE PASSCODE
9 ONLINE / OFFLINE
10 HISTORY
Configuration Menu
1 LIST CONFIGURATION
2 XCVR CONFIG
3 AOC CONFIG
4 ON-BOARD ZONES
5 AUX INPUT ZONES
6 EXPANSION ZONES
7 AUDIBLE CIRCUITS
8 RELAYS
9 ZONE ENABLE / DISABLE
10 DETACH ZONE
11 RECEIVE CONFIG
12 SEND CONFIG
13 DEFAULT CONFIG
14 AC MODE
0 RETURN TO MAIN MENU

## Using the Display and Keypad

- To activate a blank LCD, press any key
- To make a selection, use the keypad to key in the option number, and then press [ENT]
- To clear incorrectly keyed-in data, press [CE]
- To scroll information on the screen, press [ENT]
- To go back to the previously displayed menu, press [0] [ENT]

*Some menu options require a passcode entry*

## Configuration Information

- To access the configuration menu, press [1] [ENT]
- To configure transceiver information, press [2] [ENT] from the Configuration Menu
- To set up on-board zones, press [4] [ENT] from the Configuration Menu
- To set up expansion zones, press [6] [ENT] from the Configuration Menu
- To define NACs, press [7] [ENT] from the Configuration Menu


*All information is saved automatically when you exit the Configuration Menu*

## Questions & Repair

*If you have questions or require assistance, contact a Customer Service Representative at Monaco Enterprises by calling (509) 926-6277 or emailing [service@monaco.com](mailto:service@monaco.com)*



## Typical Connections - M Panel Wiring




### Notes

- 1 On-board configuration provides four Class B IDCs and NACs (each IDC or NAC has two terminals) or two Class A IDCs and NACs (each IDC or NAC has four terminals)**
- 2 Class A on-board Initiating Device Circuit (IDC) (zone) termination:** the on-board resistor is automatically connected when Class A configuration jumpers are installed. If an IDC is not used, install wire jumpers across terminal pairs 1 & 2 and 3 & 4.  
**Class A on-board Notification Appliance Circuit (NAC) (bell) termination:** the on-board resistor is automatically connected when Class A configuration jumpers are installed. If a NAC is not used, install wire jumpers across terminal pairs 1 & 2 and 3 & 4.  
**Class A expansion backplane IDC (zone) termination:** install a 3.9 kohm, 0.25 watt, 5% resistor (P/N 471-392-00) across the center terminals in the circuit. If an IDC is not used, install wire jumpers across terminal pairs 1 & 2 and 3 & 4.
- 3 Class B IDC (zone) termination:** install a 3.9 kohm, 0.25 watt, 5% EOL resistor (P/N 471-392-00) in parallel with the last device on each loop. If an IDC is used, install the resistor across the terminal pair.  
**Class B NAC (bell) termination:** install a 4.7 kohm, 0.25 watt, 5% EOL resistor (P/N 471-472-00) in parallel with the last device on each loop. If a NAC is not used, install the resistor across the terminal pair.
- 4 The position of the Class A/Class B configuration jumpers, the class setting programmed for the IDCs and NACs, and the class of wiring for the IDCs and NACs must all agree**
- 5 Polarities shown are for normal, standby (non-alarm) condition**
- 6 Form C, 1.25A/24 Vdc resistive.** These contacts may be wired for normally open (NO) or normally closed (NC) operation. Do not run the 120 Vac for auxiliary devices in the M Panel enclosure.
- 7 AUX INPUT:** These are Class B non-powered IDCs. Total loop resistance must not exceed 35 ohms per circuit.
- 8 M Panel on-board and expansion backplane IDCs (zones):** Each IDC supplies 24 Vdc filtered power for loop powered device operation / each IDC is current limited to 50 mA. Loop resistance must not exceed 35 ohms per leg.



## Expansion Backplane Wiring



- 9 **\*Bell 1, Bell 2:** These are polarity reversal NACs (bells). Each Class A NAC supplies up to 1.5 amps of 24 Vdc filtered power during an alarm condition. Each Class B NACs supplies up to 1.5 amps each. Total Bell 1 (B1 and B2) or Bell 2 (B3 and B4) current must be less than 2 amps. Loop resistance must not exceed 3 ohms per leg.
- 10 **\*AUX OUT:** This is a Class B polarity reversal circuit. It supplies up to 1.5 amps of 24 Vdc filtered power during a specific alarm condition. Loop resistance must not exceed 3 ohms per leg.
- 11 Refer to NEC and NFPA 70 for voltage drop and load center calculations.
- 12 **\*AUX PWR:** This circuit supplies up to 2 amps of 24 Vdc filtered power to auxiliary powered detectors or auxiliary devices. To use relay K2 to reset (Panel Reset) these detectors, wire the AUX PWR + output through relay K2 terminals NC and C, then to the power leads of the detectors. Configure Relay #2 for Smoke Power. A power supervisory module must be installed at the end of each power loop to provide supervision.

**CAUTION** All external relays powered by the AUX PWR circuit must be equipped with a coil suppression diode. If the relay does not have a resident coil suppression diode, install Coil Suppression Diode 1N4003 (or equivalent) by connecting the non-banded end (anode) to the negative side of the coil and the banded end (cathode) to the positive side of the coil. Failure to install this may cause damage to the Panel when the relay is de-energized.

- 13 **\*RMT TBL:** This circuit provides 150 mA of 24 Vdc filtered power to external remotely located trouble reporting devices (bells, horns, etc.). This output is non-supervised, non-polarity reversing, self current limiting. No EOL resistor is needed.

**\*IMPORTANT:** The maximum combined current of the NACs (Bell 1 and Bell 2 or Bell 3 and Bell 4), Auxiliary Output Circuit, Auxiliary Power Circuit, Remote Trouble Circuit, and IDCs provided by the backplane cannot exceed 4 amps

Fuse Description	
Power Supply PCB Assembly	
F1	10A/250V Slow Blow, 5x20 mm, Transformer Input
F2	10A/125V Fast Blow, 5x20 mm, 28 Vdc Panel Supply
F3	2.5A/250V Slow Blow, 5x20 mm, Transmitter/Receiver Supply
F4	6.3A/250V Slow Blow, 5x20 mm, Battery Charging Supply
CPU PCB Assembly	
F5	2.5A/250V Slow Blow, NAC (bell) Circuit 1
F6	2.5A/250V Slow Blow, NAC (bell) Circuit 2
F7	2.5A/250V Slow Blow, Auxiliary Output and Remote Trouble Circuits
F8	2.5A/250V Slow Blow, Auxiliary Power Circuit
Expansion Backplane	
F1	2A/250V Fast Blow, 28 Vdc Supply from M Panel
F2	1A/250V Fast Blow, 5 Vdc Supply from M Panel



## Alarm Indication and Reporting Summary

Alarm Type	LEDs Lit	LCD Displays	Panel Audible Alert	Bell Circuits	AUX OUT	Relays	Message Sent to Central	Press Switch to Acknowledge
Waterflow	ALM	AL zone input (A-#, O-#, L#-#) description	off	1 (1 & 2) 2 (3 & 4) if assigned; silenceable or nonsilenceable	on; nonsilenceable	K1 if general alarm; K2 if assigned	ALARM, ZID #	ALARM SILENCE
Supervisory	ALM	AL zone input (A-#, O-#, L#-#) description	beeps on and off	off	off	K1 if general alarm; K2 if assigned	ALARM, ZID #	ALARM SILENCE or TROUBLE SILENCE
Standard	ALM	AL zone input (A-#, O-#, L#-#) description	off	1 (1 & 2) 2 (3 & 4) if assigned; silenceable or nonsilenceable	off	K1 if general alarm; K2 if assigned	ALARM, ZID #	ALARM SILENCE
Positive Alarm Sequence	ALM	PAS ALARM sequence, then, if alarm (A-#, O-#, L#-#) description	off	1 (1 & 2) 2 (3 & 4) if assigned; silenceable or nonsilenceable	immediate; initiates pre-alarm phase. Remains on for 15 seconds if ALARM SILENCE is not pressed.	If alarm: K1 if general alarm; K2 if assigned	ALARM, ZID # (if alarm)	ALARM SILENCE PANEL RESET
Detector Verification	ALM	AL zone input (A-#, O-#, L#-#) description	off	1 (1 & 2) 2 (3 & 4) if assigned; silenceable or nonsilenceable	off	K1 if general alarm; K2 if assigned	ALARM, ZID #	ALARM SILENCE
Tamper	TBL	TB zone input (A-# only) description	on steady if programmed to turn on	off	off	K1 if general trouble; K2 if assigned	TAMPER, M #	TROUBLE SILENCE
Master Box Operation	ALM	AL zone input (A-#, O-#, L#-#) description	off	off	on for 3 seconds	K1 if general alarm; K2 if assigned	ALARM, ZID #	ALARM SILENCE
No Bell	ALM	AL zone input (A-#, O-#, L#-#) description	off	off	off	K1 if general alarm; K2 if assigned	ALARM, ZID #	ALARM SILENCE
No Bell (Auto Reset)	ALM	AL zone input (A-#, O-#, L#-#) description	off	off	off	K2 if assigned	ALARM, ZID #	ALARM SILENCE

\*When the panel audible alert is activated, any remote trouble reporting device connected to the RMT TBL terminals is also activated. When the panel audible alert is silenced, the remote trouble reporting device is also silenced.

**NOTE:** If AOC outputs have been programmed as general alarm, they activate when an alarm occurs on any zone. AOC outputs programmed for general trouble activate for a Tamper-type alarm. AOC outputs assigned for specific zones activate for alarms or troubles as programmed for that zone. AOC alarm outputs for Waterflow, Positive Alarm Sequence, and Detector Verification type zones only activate when the alarm is processed by the M panel.

### Switches

- **ALARM SILENCE** Press to acknowledge an alarm condition and silence the NACs
- **TROUBLE SILENCE** Press to acknowledge a trouble condition and silence the Panel Audible and Remote Trouble
- **PANEL RESET** Press to clear an alarm condition
- **LAMP TEST** Press to test audible alert and LED operation
- **DRILL TEST** Press to test evacuation signaling device operation when no alarm conditions exist
- **XMTR RESET** Press to return the transceiver to operation after a fault condition shutdown



## LEDs

- **AC POWER** Operation on ac power
- **BATTERY** Operation on backup battery power
- **FAULT** Microprocessor problem
- **ALM/TBL** Alarm or trouble condition
- **XMT/RCV/CD** Transmissions sent, received, or detected
- **XMTR DISC** M Panel transceiver shut down due to a fault