

5800 Wireless Replacement Battery Chart



Product	Battery Type
5800CO	CR123
5800MICRA	CR1620 coin cell
5800PIR-RES	CR123
5800PIR	CR123
5800PIR-COM	CR123
5800PIR-OD	AA lithium (Qty 4)
5800RPS	CR1620 coin cell
5800SS1	CR2
5800WAVE	WALYNX-RCHB-SC
5801	CR123
5802	CR1/3N (not replaceable)
5802MN	CR2032 coin cell
5804	CR2025 coin cell (Qty 2)
5804BD	CR2430 (Qty 2)
5804BDV	CR2430 (Qty 2)
5804Watch	CR2025 coin cell
5805-6	CR2032 coin cell
5806	9 volt alkaline (Qty 2)
5808	CR123 (Qty 2)
5808LST	CR123 (Qty 2)
5808W3/5806W3	CR123
5809	CR123
5811	CR2032
5811BR	CR2032
5814	CR2430
5815	CR123
5816	CR123

Product	Battery Type
5816MN	CR123
5817	CR123
5817CB	CR123
5818	CR123
5818MNL	AAA lithium*
5819	CR123
5819WHS	CR123
5819BRS	CR123
5820L	AAA lithium*
5821	CR123
5827	9 volt alkaline
5828V	AA alkaline (Qty 3)
5839	9 volt Lithium
5853	CR123 (Qty 2)
5869	CR123
5870API-WH	CR2
5870API-GY	CR2
5878	CR2032 coin cell
5890	CR123 (Qty 2)
5890PI	CR123 (Qty 2)
5894PI	CR123 (Qty 3)
5897-35	CR123 (Qty 4)
5898	AA lithium (Qty 4)
LYNX Plus/LYNX Touch	LYNXRCHKIT-HC LYNXRCHKIT-SC LYNXRCHKIT-SHA



- Unless specified, quantities are one per product.
- Refer to the instructions of the product for approved battery brands.

*Lithium is recommended, however Alkaline will also work but with shorter battery life.