Installation Instructions



AV-AMP-80



Øр Øр Ø Ø 10 10 10 A B RS485 0 TROUBLE OW NO NC Π 0 10 10 10 000000 Ø AMP-2 SPKR B- A- # 10 100 OUT+ IN-AMP2IN 100 * Mounting Tabs 10 10 AMP1IN 10 AMP-1 SPKR B- A- A \oslash Ø

Figure 1 – AV-AMP-80 Audio Amplifier Module Mounting

www.advancedco.com

These instructions cover the installation and replacement of the AV-AMP-80 audio amplifier module.

The AV-AMP-80 audio amplifier module is mounted below the AX-CTL base card on the left side of the enclosure.

Refer to separate wiring diagrams and manuals for addition module installation wiring, operation and programming functions.

AX-CTL-1L, AX-CTL-2 and AX-CTL-4: Wiring Diagram: 670-1233	Product Manual: 682-001	Program Manual: 682-002
AX-CTL-1V, AX-CTL-2V and AX-CTL-4V: Wiring Diagram: 670-1233	Product Manual: 682-001V	Program Manual: 682-002
AX-CC1-16, AX-CC2-16, AX-CC4-16 and Command Centers CCM-01/CCM-02:		

Wiring Diagram: 670-1233 Product Manual: 682-001CC Program Manual: 682-002

Caution: Before installing or removing any printed circuit boards remove all sources of power (AC and battery).



This equipment is constructed with static sensitive components. Observe anti-static precautions at all times when handling printed circuit boards. Wear an anti-static ground strap connected to panel enclosure earth ground.

Note: The AV-AMP-80 audio amplifier module is preassembled to a metal mounting plate. When replacing an AV-AMP-80 module <u>do not remove the module from the metal mounting plate</u> as it is required for module heat sinking. The new AV-AMP-80 audio amplifier module will be provided with its own metal mounting plate.

Installation (see figure 1 and 2):

[1] Slide the AV-AMP-80 audio amplifier module mounting plate tabs [*] under the two (2) tabs located on the lower left side of the system backbox below the AX-CTL base card.

[2] Secure the top end of the AV-AMP-80 audio amplifier module mounting plate to the two (2) backbox standoffs with the two (2) screws provided [p].

[3] Wire field wiring as indicated in figure 2 and in associated product manuals.

Replacement (see figure 1 and 2):

- [1] Remove all field wiring terminal blocks.
- [2] Remove the two (2) screws securing the AV-AMP-80 mounting plate to the system backbox [p].

[3] Carefully slide the audio amplifier assembly from under the backbox mounting tabs [*] located on the left side of the audio amplifier mounting plate.




Figure 2 – AV-AMP-80 Audio Amplifier Module Wiring





 100 South Street, Hopkinton, Massachusetts 01748

 Tel: (508) 435-9995
 Fax: (508) 435-9990

 Email: usa@advancedco.com
 Web: www.advancedco.com